



Gartenhaus Monika

Die Teile vorsichtig mit einem scharfen Messer oder besser Skalpell aus den Platten lösen.
Zuerst Fenster und Türen von innen auf die Wände kleben und ausrichten, dann die Scheiben aufkleben.
Dann zuerst die Wände mit den Zapfen in die Grundplatte kleben, danach die übrigen Wände einsetzen und den Tragbalken für das Dach in das vorgesehene Loch einsetzen.
Die Zaunpfähle in die Löcher kleben und die Zaunteile an den passenden Stellen aufkleben. Die übriggebliebenen Pfähle dienen als Blumenkästen.
Jetzt das Kartondach knicken und aufkleben.
Dann die Dachplatten so aufkleben dass am First ein passender Spalt für die Firstziegel bleibt.
Zum Schluss Firstziegel aufkleben.

Klebstoff: Holzleim und Sekundenkleber (Scheiben) oder Dispersionskleber

Garden house Monika

Carefully remove the parts from the panels with a sharp knife or, better still, a scalpel. First glue and align the windows and doors from the inside on the walls, then glue the panes on. Then first glue the walls with the tenons into the base plate, then insert the remaining walls and insert the supporting beam for the roof into the hole provided. Glue the fence posts into the holes and glue the fence parts in the appropriate places. The remaining stakes serve as flower boxes. Now fold the cardboard roof and glue it on. Then glue on the roof panels so that a suitable gap remains for the ridge tiles on the ridge. Finally glue on the ridge tiles.

Glue: wood glue and superglue(Discs) or dispersion glue